



DS3011 PARTS LIST

5/1/2012

FIG.	PART NO. LIST	DESCRIPTION	NO. REQ.
1	6041253	Aluminum Base w/chain	1
2	FE-1 4-25E1 10V	Fein Motor 1 10V 60Hz with 5/8"-1 1 threads	1
3	IPT-DS03	Round Head Screw 10-24X1-1/4"	3
4	6041255	External Snap Ring for ER24 Bearing	1
5	6041256	Sprocket with 5/8"-1 1 threads	3
6	6041257	Plastic Spur Gear	1
7	6041258	Steel Spur Gear with 5/8"-1 1 Threaded	1
8	IPT-DS301X16	Plastic Cover Ring	1
9	IPT-DS09	Socket Head Cap Screw 1/4-20x2.0" SS	5
10	6041260	Cover Plate	1
11	6041261	Flat Head Tapping Screw 10x1.0" SS	3
12	6041262	Rigid Back Up Pad 5" with 5/8"-1 1	3
14	6041264	External Snap Ring for ER12 Bearing	3
15	IPT-TS78	Ball Bearing ER12	3
16	IPT-DS301116	Steel Ring 4.5"	2
17	6041267	Center Ball Bearing ER24	1
18	IPT-BHA	Garden Hose Adapter	1
19	IPT-JGA	Hose Fitting	3
20	IPT-CT14	Water Hose	1
21	6041271	Brass Ball Valve	1
22	6041272	Steering Wheel Cap	4
23	6041273	Bracket	1
24	6041274	Binding Head Screw 1/4-20x1/2" SS	6
26	6041276	Steering Wheel	1
27	6047206	Vacuum 90 Deg Elbow	1
28	6047207	Vacuum Adapter 2-1/2"	1
29	IPT-DS301 129	Slurry Skirt 44"	1
32	6041279	Wrench	1
35	IPT-DS35	Shipping Container (Not shown)	1
36	IPT-DS36	WPO14-25E Air Adapter	1